

Suggested Wash Formulas & Chemical Supplies for Healthcare Gowns

Cycle	Water Level	Temp (F)	Time (Min)	Chemicals/100lbs(CWT)
Break	Low	150	8	4-5oz Alkali, 3-4oz Detergent
Bleach	High	165/150	8	5-6oz Hydrogen Perozide or 5-7oz Chlorine Bleach
Rinse	High	150	2	-----
Rinse	High	135	2	-----
Rinse	High	120	2	-----
Sour	Low	100	2	1 oz Sour (pH 5.5 - 6.5)

Each healthcare laundry should consult their wash chemical supplier for exact formulas based on expectations, equipment, and water conditions.

Finishing: Whether goods are dried or tunnelled, the peak temperature of the garment fabric should reach 285°F - 300°F.